


EASY PUMP SELECTION GUIDE

Simply check if your distance and height is below the blue line on the chart. If it is, then the pump will be able to pump the water out. If not, check other models. It is important that you take note of the flow rate and pipe size listed against each model.

RVS155 Distance v Height Graph

Constants: 80L/min, 40mm Pressure Pipe






RVS250 Distance v Height Graph

Constants: 120L/min, 40mm Pressure Pipe





Distance (m)

RVS300 Distance v Height Graph

Constants: 160L/min, 50mm Pressure Pipe



